DO NOT EXCEED WORKING LOAD LIMIT.
USE ONLY G80 & G100 COMPATIBLE COMPONENTS FOR OVERHEAD LIFTING.



Safe Lifters

Pundol Apartments, Shop No. 5 & 6, 160 M.G. Road, Pune - 411001. (India) Tel +91 20 66013783 / 84 / 85 / 86 Fax +91 20 26350832 Email: safelifters@eth.net

Screw Clamp

The screw clamp offers many possible applications. It is particularly useful for lifting, transferring and pulling sheet metal, girders and steel constructions.

Please note that the spindle must be handtightened to the material.

Once the screw clamp is tightened and lifting begins, the pivoting pad clamping system produces a wedging action against the material, holding it securely.



Model	Capacity t	Jaw capacity Z mm	weight kg	A mm	B mm	Ø C mm	D mm	E mm	F mm	X mm
SLSC70-1,5	1,5	0 - 32	7,4	255	65	26	75	130	44	40
SLSC70-3,0	3,0	0 - 50	11,4	290	74	30	85	170	50	40
SLSC70-5,0	5,0	0 - 80	27,6	470	130	50	135	225	72	50



